

# Huolto-ohje

## iBombo polkupyörän huoltopiste

Säännöllinen polkupyörien huoltopisteiden huolto ja puhdistus pidentää tuotteen ikää ja varmistaa hyvän käyttökokemuksen. Valmistaja on myös tuottanut sarjan opasvideoita asiakkaiden käyttöön.

Tässä ohjeessa:

- Yleiset huolto-ohjeet
- Varaosakuvasto
- Valmistajan takuehdot

Vinkkejä polkupyörän huoltoon: <https://www.ibombo.eu/repair/>

### Valmistajan huolto-ohjeet:

1. Maalatut pinnat tulisi säännöllisesti puhdistaa. Suosittelemme puhdistusta kerran kuukaudessa. Puhdistuksen jälkeen maalipinta tulisi käsitellä synteettisellä vahalla, esimerkiksi "Meguiars Ultimate Liquid Wax".
2. Työkalut ovat oleellinen osa huoltopistettä ja niistä on pidettävä huolta ja voidella.
3. Mikäli huoltoteline asennetaan ulkotiloihin, jossa se altistuu kylmyydelle ja sään vaihteluille, tulee huoltotelineen huoltoväliä lyhentää ja käyttää korroosiota estäviä voiteluaineita.
4. Talvella huoltopistettä ei tulisi asentaa sellaiseen kohteeseen, jossa on suolausta, hiekoitusta tai muita aineita, jotka saattavat nopeuttaa korroosiota.
5. Työkaluja tulisi voidella vähintään kerran kuukaudessa esimerkiksi Molydal Top 5, Tectyl Glashelder tai vastaava aine.
6. Ilmapumpun mäntä tulisi voidella vähintään kuukausittain vaseliinilla, esimerkiksi Motorex Fett 2000 tai silikonirasvalla.
7. Valmistaja on parhaimman mukaan valinnut kestävimät työkalut huoltopisteeseen.
8. Valmistaja on tuottanut opastusvideoita tuotteen hankkijoille.
  - INSTALLATION MANUAL  
<https://vimeo.com/493915888> -
  - PUMP AND ADAPTER MAINTENANCE TIPS  
<https://vimeo.com/495337519>
  - TOOL MAINTENANCE TIPS  
<https://vimeo.com/499137789>
  - MAINTENANCE AND CLEANING OF THE POWDER COATING  
<https://vimeo.com/499361857>



- REPAIR OF POWDER PAINTED DAMAGE  
<https://vimeo.com/499378911>
- PUMP FULL MANUAL  
<https://vimeo.com/482354908>
- THREAD REPAIR AND DRILLING  
<https://vimeo.com/500491713>
- IBOMBO PRS-LV2 (MANUAL - PUMP & HOSE EXCHANGE)  
<https://vimeo.com/482361597>
- IBOMBO PRS-LV2 (MANUAL - TOOL EXCHANGE)  
<https://vimeo.com/480849551>
- IBOMBO PRS-sV1 & PRS-sV20 (MANUAL - TOOL EXCHANGE)  
<https://vimeo.com/480896236>
- IBOMBO PRS-sV1 & PRS-sV20 (MANUAL - PUMP EXCHANGE)  
<https://vimeo.com/480896630>
- IBOMBO PRS-sV1 & PRS-sV20 (MANUAL - HOSE EXCHANGE)  
<https://vimeo.com/480897164>
- IBOMBO SCANDIC (MANUAL - PUMP & HOSE EXCHANGE)  
<https://vimeo.com/480897757>
- IBOMBO SCANDIC (MANUAL - TOOL EXCHANGE)  
<https://vimeo.com/480798464>
- IBOMBO SCANDIC (INSTALLATION OF THE DOOR AND COIN LOCKING SYSTEM)  
<https://vimeo.com/500477639>
- Videoiden salasanaa ei saa luovuttaa kolmannelle osapuolelle.  
Salasana: !IBOMBO!@

Mahdollisissa ongelmatilanteissa ole yhteydessä myyntiin, [myynti@trafino.fi](mailto:myynti@trafino.fi) .



# Varaosakuvasto





No. 141



No. 140



No. 142



No. 118



No. 153



No. 159



No. 156



No. 155



No. 157



No. 154



No. 145







## GUARANTEE

**Producer (Guarantor):** **IBOMBO RIDE & BE HAPPY**  
 Leśna Osada 15, 64-100 Leszno  
 NIP (Tax Identification Number) PL 697-225-93-26

**Guarantee subject:** **IBOMBO PRS-LV2, IBOMBO PRS-SV1, IBOMBO PRS-SCANDIC  
 IBOMBO PRS-sV20 (galvanized steel)**

**Date of sale:** .....

## GUARANTEE TERMS AND CONDITIONS

1. The Guarantor assures that the quality of the guarantee subject shall be in accordance with its purpose for the period of 24 months, subject to the provisions of this guarantee.
2. The Guarantor shall eliminate free of charge physical defects of the guarantee subject if the defects are detected within the duration of the guarantee and all requirements and stipulations of this guarantee document are met.
3. The existing defect shall be reported in writing and within 5 days from the day it is detected.
4. The Guarantor shall be obliged to start actions aimed at investigating the complaint and/or eliminating the defects covered by this guarantee within 14 working days from the day the complaint is received. Together with the complaint, relevant photographic documentation should be delivered (ISO  $\geq$  400, resolution  $\geq$  2560x1920 px, min. 5Mpx).
5. This guarantee shall not cover:
  - a. mechanical damages of the guarantee subject done by the purchaser or third parties;
  - b. damages and defects which result from misusing the guarantee subject;
  - c. damages and defects which result from storing the guarantee subject in a way contrary to the producer's recommendations and/or technical knowledge;
  - d. damages and defects which result from not preserving technological regimes while installing and/or maintaining the guaranty subject;
  - e. a situation when the purchaser and/or any third party started repairing or tried to repair the guarantee subject on their own without consulting it with the producer of the stand.
6. This guarantee shall cover the following elements of the guarantee subject:
  - a. casing of the stand;
  - b. tool set placed in the stand;
  - c. bicycle pump.
7. In case of the casing of the stand, the guarantee shall be valid for 24 months and shall cover:
  - a. no paint adhesion
  - b. defects related to chalking of the coating bigger than defined by ASTM D659;
  - c. defects of colour change bigger than 10 CIELAB units when compared to the original colour in accordance with ASTM D2244;
  - d. defects of loss of sheen bigger than 70% in accordance with ISO 2813.
8. In case of the casing of the stand, the guarantee shall not cover:
  - a. mechanical and chemical damages to the coating, in particular caused by maintaining the guarantee subject with the use of unsuitable cleansing agents – to clean the guarantee subject, one should use clean water with a small amount of neutral or slightly alkaline detergents, it is forbidden to use strong acid or strong alkaline detergents and also surface-active agents; it is forbidden to use organic solvents which include esters, ketones, alcohols, aroma compounds, glycol esters, chlorinated hydrocarbons etc.; it is forbidden to use detergents of unknown origin and/or composition; it is forbidden to use abrasive cleaners or to clean the surface through rubbing; greasy, oily and/or tarry smudges can be removed with petroleum derivative solvents without aromatic substances; used detergents cannot react with the surface being cleaned for longer than one hour; after each cleaning, the surface has to be immediately washed with clean cold water; the pH of detergents used to clean should be 5 – 8;
  - b. damages due to the user's fault;
  - c. damages caused due to fire, vandalism, military activities, disasters and/or cataclysms;
  - d. defects of the coating due to using the coated elements in aggressive environment;
  - e. defects of the coating due to their improper maintenance while using;
  - f. defects of the coating which are not bigger than 5% of the whole facade or are not visible from 3 meters from a public place;



9. Powder-coated surfaces have to be periodically cleaned – not less often than once a month, and after cleaning - waxed, the producer recommends to use synthetic wax – Meguiars Ultimate Liquid Wax .
10. The tools are elements of the stand replaced periodically, in order to prevent corrosion, the tools have been covered with suitable layers – tyre levers with nylon, screwdrivers with plastics, hex keys with Proguard, an open-end wrench and an adjustable wrench are chromium-plated and were treated with preservatives.
11. The tool set and the pump from 30 November to 30 March have to be stored inside buildings, otherwise the guarantee rights shall be deemed null and void. Also not within the mentioned period, the tool set has to be stored inside buildings under pain of nullity provided the air temperature falls regularly below 2°C.
12. In winter, it is forbidden to use within the area where the stand is placed sand with salt or any other substances which may speed up corrosion processes.
13. The tool set should be regularly – not less often than once a month – maintained with the agents recommended by the producer – Molydal Top 5, Tectyl Glashelder spray.
14. The piston of the pump should be regularly maintained – not less often than once a month – with the agent recommended by the producer – Motorex Fett 2000 or silicone grease.
15. The tools have been prepared by the producer in a way making them useful as long as it is possible.
16. Instructions on the correct installation and maintenance of the Bicycle Repair Station are available in electronic form at the following addresses:
  - a. installation manual - <https://vimeo.com/493915888>;
  - b. pump and pump adapter maintenance - <https://vimeo.com/495337519>;
  - c. tool maintenance - <https://vimeo.com/499137789>;
  - d. maintenance of the paint coating - <https://vimeo.com/499361857>.
17. In order to obtain the passwords to play the video materials referred to in section 4, please contact the Seller via e-mail at [biuro@ibombo.com](mailto:biuro@ibombo.com).
18. Provided the requirements specified in this guarantee are met, in case of the tools placed in the stand the guarantee shall cover:
  - a. manufacturing and material defects of the tools detected within the guarantee period;
  - b. corrosion of the tools provided they are marked as rustproof and have been stored inside buildings.
19. Notwithstanding anything to the contrary in this guarantee, in case of the tool set placed in the stand the guarantee shall not cover:
  - a. tools which have been misused;
  - b. natural wear of the tools, in particular the ends of the screwdrivers, keys and wrenches;
  - c. damages or defects which result from misusing the tools and/or using them for other than intended use;
  - d. damages which result from changes and modifications of the stand and/or tools performed by the purchaser or any third party;
  - e. tools which from 30 November to 30 March were stored outside buildings and exposed to adverse weather conditions (falls, low temperatures, high humidity).
20. In case of the bicycle pump placed in the stand the guarantee shall not cover:
  - a. damages which result from misusing the pump or using it for other than intended use;
  - b. normal wear of a part of the pump, including in particular ends of adapters and gaskets.
21. In case of mechanical damages to the bicycle pump adapter, gaskets due to their misusing and/or in case of the wear of the pump adapter, gaskets, it shall be possible to try to repair the fault on one's own.
22. The guarantee shall be valid within the territory of European Union.
23. The guarantor shall not be responsible for damage to property and/or to health due to using the guarantee subject which results from using it for other than intended use and operating conditions.
24. Any complaint shall not entitle to withhold payment for the purchase of the guarantee subject.

